

TABLE OF CONTENTS

WARRANTY
FEATURES & OPERATING CONTROLS
PRECAUTIONS & GENERAL INFORMATION
AGENCY LISTING INFORMATION
INSTALLATION
OPERATION
CLEANING INSTRUCTIONS
TROUBLESHOOTING SUGGESTIONS
MAINTENANCE INSTRUCTIONS
EXPLODED VIEW & PARTS LIST
WIRING DIAGRAM
PARTS & SERVICE
CUSTOMER SERVICE DATA

INTRODUCTION

Thank You for purchasing this Wells Manufacturing appliance.

Proper installation, professional operation and consistent maintenance of this appliance will ensure that it gives you the very best performance and a long, economical service life.

This manual contains the information needed to properly install this appliance, and to use and care for the appliance in a manner which will ensure its optimum performance.

SPECIFICATIONS

MODEL	DESCRIPTION	VOLTS	AMPS	WATTS	PHASE	NEMA PLUG
SMPT	12" x 20" RECTANGLE.	120V	13.8	1650	1	4' 5-15P
		120C	11.7	1404		
SMPTD	12" x 20" RECTANGLE w/DRAIN	120V	13.8	1650		
SMPT	12" x 20" RECTANGLE	208/240	5.9 - 6.9	1240/1650	1	4' 6-15P
SMPTD	12" x 20" RECTANGLE w/DRAIN					
SMPT27 / SMPTD27	12" x 27" RECTANGLE w & w/o DRAIN	120V	13.8	1650	1	4' 5-15P
		120C	11.7	1404		
		208/240	6.0 - 6.9	1240/1650	1	4' 6-15P
SW-10T	11 Qt. ROUND	120V	6.9	825	1	4' 5-15P
TMPT	2 - 12" x 20" RECTANGLE	120V	15	1800	1	4' 5-20P
TMPTD	2 - 12" x 20" RECTANGLE w/ DRAIN					
TMPT	2 - 12" x 20" RECTANGLE	208/240	8.7 - 10.0	1800/2400	1	4' 6-15P
TMPTD	2 - 12" x 20" RECTANGLE w/ DRAIN					